




Parts Identification Guide
PIL010/0205




Powder Loader





Powder Loader

- 1. Accumulator
- 3. Compressed Air Filter
- 6. Latch
- 7. Pressure Gauge
- 8. Pressure Regulator
- 10. Solenoid
- 11. Universal Terminal Box



Powder Loader

- 1. Accumulator
- 2. Air Cylinder
- 4. Filters
- 5. Gasket
- 9. Sequencing Valve Assembly