



Parts Identification Guide
PIC008/0205



Ratio Valve





RV Modular Valve Parts

- 1. Air Cylinders
- 2. Outlet Tube
- 3. Solenoid Valve
- 4. Inlet Tubes
- 5. Sight Glass
- 8. Cover Gasket



RV Modular Valve Parts

- 1. Air Cylinders
- 2. Outlet Tube
- 3. Solenoid Valve
- 4. Inlet Tubes
- 6. Valve Stoppers
- 7. Rubber Seal Rings