





Parts Identification Guide
PIC012/0205




Positive Displacement Pump 3, 5, 7.5 HP





**Positive Displacement Pump
3, 5, 7.5 Hp**

- 1. Belt Guard
- 2. Filter Assembly
- 3. Motor
- 5. Relief Valve
- 6. Sheave / Drive Bushing
- 7. V Belt
- 8. Vacuum Gauge
- 9. Vacuum Pump
- 10. Sheave / Drive Bushing



**Positive Displacement Pump
3, 5, 7.5 Hp**

1. Belt Guard
2. Filter Assembly
4. Muffer
5. Relief Valve
6. Sheave / Drive Bushing
7. V Belt
8. Vacuum Gauge
10. Sheave / Drive Bushing