



Parts Identification Guide  
PIC001/0205



# Dustbeater







DB Dustbeater Vacuum Loader Parts

- 1. Vacuum Motor
- 2. Tube Fitting
- 3. Flapper
- 4. Rubber Seal Ring
- 5. Universal Terminal Box
- 6. Loader Control
- 7. Latch
- 8. Solenoid Valve



### DB Dustbeater Vacuum Loader Parts

1. Vacuum Motor
2. Tube Fitting
5. Universal Terminal Box
6. Loader Control
7. Latch
8. Solenoid Valve
9. Dacron Filter
10. Reed Switch
11. Compressed Air Line Filter





**DB Dustbeater Vacuum Loader Parts**

- 1. Vacuum Motor
- 2. Tube Fitting
- 3. Flapper
- 4. Rubber Seal Ring
- 5. Universal Terminal Box
- 6. Loader Control
- 7. Latch
- 8. Solenoid Valve
- 10. Reed Switch
- 11. Compressed Air Line Filter

**RV Modular Valve Parts**

- 12. Ratio Valve
- 13. Inlet Tubes
- 14. Air Cylinder
- 15. Outlet Tube
- 16. Solenoid Valve




**DB Dustbeater Vacuum Loader Parts**

- 3. Flapper
- 4. Rubber Seal Ring
- 5. Universal Terminal Box
- 6. Loader Control
- 11. Compressed Air Line Filter

**RV Modular Valve Parts**

- 12. Ratio Valve
- 13. Inlet Tubes
- 14. Air Cylinders
- 15. Outlet Tube
- 17. Sightglass





DB Dustbeater Vacuum Loader Parts

- 5. Universal Terminal Box
- 6. Loader Control
- 7. Latch
- 8. Solenoid Valve
- 9. Dacron Filter
- 10. Reed Switch
- 18. ID Tag

RV Modular Valve Parts

- 14. Air Cylinders
- 15. Outlet Tube
- 16. Solenoid Valve



**RV Modular Valve Parts**

- 13. Inlet Tubes
- 14. Air Cylinders
- 18. Valve Stopper
- 19. Rubber Seal Rings

**Brushless Motor**

- 20. Brushless Motor
- 21. Brushless Motor Filter